LAB 06 THE IKS01A2 MODULE



Prof. Davide Brunelli

Dept. of Industrial Engineering – DII
University of Trento, Italy
davide.brunelli@unitn.it

PRELIMINARY DOWNLOADS

PRELIMINARY DOWNLOADS

Before we start, please download all the file contained inside the drive folder:

https://drive.google.com/drive/folders/1BfbaYt5Bvy6v2NRF1YHIKbplc5kHMwEZ?usp=sharing


I2C

STM32 12C

Inter Integrated Circuit (**I2C**) is a serial communication protocol for exchanging data between a **master** and one or more **slaves**.

The I2C allows for synchronous communication thanks to a line reserved for the clock signal (SCL – Serial Clock). Data are exchanged through a second line called SDA – Serial Data.

Addressing is done with a single line by using the address slave.




STM32 I2C

Pin PB8 and PB9 can be multiplexed to the SCL and SDA lines.

PB8 = I2C SCL


PB9 = I2C SDA



STM32 USART

I2C parameters can be configured as always using CubeMX.

As a first step, set **I2C** as the **I2CI mode**. We will come back later on this.




X-NUCLEO-IKS01A2

X-NUCLEO-IKS01A2

The X-NUCLEO-IKS01A2 is a motion MEMS and environmental sensor evaluation board system.

- LSM6DSL: MEMS 3D accelerometer (±2/±4/±8/±16 g) + 3D gyroscope (±125/±245/±500/±1000/±2000 dps)
- LSM303AGR: MEMS 3D magnetometer (±50 gauss) +
 MEMS 3D accelerometer (±2/±4/±8/±16 g)
- LPS22HB: MEMS pressure sensor, 260-1260 hPa absolute digital output barometer
- HTS221 : Capacitive digital relative humidity and temperature
- DIL 24-pin : Socket available for additional MEMS adapters and other sensors (UV index)



HTS221 LSM6DSL ST morpho connector**

LPS22HB LSM303AGR Arduino UNO R3 connector


X-CUBE-MEMSI


X-CUBE-MEMSI


The X-CUBE-MEMSI software package is an expansion for STM32Cube, associated with the X-NUCLEO-IKS01A2 expansion board.

- Complete middleware to build applications using temperature and humidity sensors (HTS221), pressure sensor (LPS22HB) and motion sensors (LSM303AGR and LSM6DSL)
- Sample application to transmit real-time sensor data to a PC
- PC-based application (Windows®) to log sensor data
- Low-power optimization (suitable for the STM32L0 MCU family)
- Free, user-friendly license terms


Overall Software Architecture









Once updated, close it and re open it as an administrator





Once updated, close it and re open it as an administrator




X-CUBE-MEMSI – UNICLEO GUI

Unicleo-GUI is a graphical user interface (GUI) for the X-CUBE-MEMSI software expansions and STM32 Nucleo expansion boards like the X-NUCLEO-IKS01A1.

The main objective of this application is to demonstrate the functionality of the embedded ST sensors and


algorithms.




X-CUBE-MEMSI – UNICLEO GUI

Install it by unzipping the **en.Setup_Unicleo.zip** archive and **run the executable**.


Be sure to check the *Install Virtual COM Port Driver* option.





X-CUBE-MEMSI – UNICLEO GUI




If you get this error, just browse for the path were you installed the Unicleo-GUI, look for the opengl32sw.dll file and rename it as opengl32.dll








Scroll down and check IKS01A2 as Board Extension



Here you can select the pre-compiled application to test.


Select


IKS01A2_DataLogTerminal





From the **Pinout** scheme, if not already set, set:

Nucleo 64		
PIN	Mode	Label
PB5	GPIO_EXTI5	
PB4	GPIO_EXTI4	
PB10	GPIO_EXTI10	
PA2	USART2_TX	USART_TX
PA3	USART2_RX	USART_RX
PA5	GPIO_Output	LD2 [Green Led]
PC13	GPIO_EXTI13	B1 [Blue PushButton]

























Download the Firmware package and you are ready to go!







Once you flash the firmware, you can visualize the streaming data through MobaXTerm by setting a **Serial session with Baudrate I I 5200**


IKS01A2 – 6D ORIENTATION ESTIMATOR

6D ORIENTATION ESTIMATOR

Import the 6D Orientation estimator application and flash it on your Nucleo board.

- I. Use CubeMX to select the **IKS01A2_LSM6DSL_6DOrientation** in Software Packs->Select Components as we have done for the datalogger.
- 2. Set the Platform settings as shown in the next slide
- 3. Flash your Nucleo board.
- 4. Look at the data streaming using MobaXTerm.


6D ORIENTATION ESTIMATOR




Access the X-Cube-MEMS Software pack


IKS0IA2 – TESTING APPLICATIONS WITH THE UNICLEO GUI

Extract the archive en.stsw-link007_V2-36-26.zip and run the **STLinkUpgrade** file in stsw-link007->AllPlatforms



If not greyed out, hit the **Upgrade** option to upgrade your ST-LINK firmware







Unzip the *Applications_L476RG.rar* archive, enter the *IKS01A2* folder and click on the folder of the application you want to flash onto the Nucleo board.


Then enter the *Binary* folder and copy the .bin file onto your Nucleo board (access your board by clicking on the NODE_L476RG drive)

Run the Unicleo-GUI, select the proper COM port and hit **Connect**





Click on the icon with the name of the flashed application to **visualize its HMI**



Unicleo-GUI Datalog Motion MEMS You can even visualize additional data Environ-mental 🚧 Magnetometer Scatter Plot Scatter 400 mG 200 mG **ECompass** 100 mG Time Statistics 1020 hPa Off-line Data -100 mG 1019.5 hPa Controll 1019.25 hPa -200 mG Firmware Version = 8,2,0 Expansion Board: IKS01A2 -600 mG Reset model Autoscale is ON Clear Lines

Environmental Sensor Plot

ADDITIONAL RESOURCES

You can find a complete overview of Cube MEMS as well as all the details for the applications contained in the Applications.rar archive in the pdf **STMicroelectronics.X-CUBE-MEMSI_GettingStarted**.

You can find a complete overview of the Unicleo-GUI in the pdf dm00337036

This two pdf as well as all the file mentioned in these slides are contained in the drive folder:

https://drive.google.com/drive/folders/1BfbaYt5Bvy6v2NRF1YHIKbplc5kHMwEZ?usp=sharing