
## LAB 03 TIMERS



#### **Prof. Davide Brunelli**

Dept. of Industrial Engineering – DII
University of Trento, Italy
davide.brunelli@unitn.it

A hardware timer is essentially an **independent counter** that counts from zero to its maximum value at a given speed and generates various events. It runs in the background independently from your C/C++ program and its value typically follows the sequence depicted below:



It is basically a **global variable** (timer counter) that **increments** (or **decrements**) on the basis of a **programmable clock source** 

The hardware of a timer is composed of **three basic programmable parts**:


- The clock source: the circuit that generates the clock tick for the timer
- The **time base**: the circuit that **derives the time granularity** from the clock source and contains the timer counter variable
- The slave circuits: provide additional functions (pulse measure, signal generation, etc.) by exploiting the timer variable

The **STM32 MCU** offers up to 11 different **timer/counters** with the following features:

- Clock selection (internal, external, other)
- 16/32-bit counter resolution
- Programmable prescaler
- Four independent channels configurable as:
  - Input Capture
  - Output Compare
  - PWM Mode
  - One-pulse Output
- Interrupt generation on the basis of the various events that can occur

Counting is handled in the **time-base** by the following registers:


- TIMx->PSC: the prescaler register; it directly specifies the division factor
- **TIMx->CNT**: the counter register; it holds the counter value and increments (or decrements) it according to the input clock
- TIMx->ARR: the auto-reload register; CNT counts from 0 to ARR, then CNT is set to 0 again
- When **CNT** is **reloaded**, an **update event** is generated (the "**U**" in figure) which can trigger an **interrupt generation**



The STM32 embeds **multiple timers** providing timing resources for software or hardware tasks.


The software tasks mainly consist of providing time bases, timeout event generation and time-triggers.

The hardware tasks are related to I/Os: the timers can generate waveforms on their outputs, measure incoming signal parameters and react to external events on their inputs.




We will use **TIM6** for our board.


**TIM6** is a simple Timer acting as a **Counter**. It just counts the clock cycles up to the maximum value set and then reset.



Timer tick time (or timer resolution) is base on APBx clock. It can be scaled using a 16 Bit prescaler. We can modify the base clock, to simplify the pre-scaler division.



$$t_{TIMx} = \frac{\text{Prescaler} + 1}{APBx_{CLK}}$$




$$Period = \frac{T \cdot APBx_{CLK}}{Prescaler + 1} - 1$$

$$t_{TIMx} = \frac{\text{Prescaler} + 1}{APBx_{CLK}}$$

#### STM32 TIMERS – INTERRUPT

We can activate the interrupt using the NVIC configuration tab in CubeMX



#### STM32 TIMERS – INTERRUPT

Once the timer has reached its counting period, an interrupt will be fired. Using the proper callback function we can create timed tasks (like the blinking of a LED)

After the Peripheral Initializations, remember to start TIM6 In Interrupt Mode.

```
void HAL_GPIO_EXTI_Callback(uint16_t GPIO_Pin)

Kart the timer

HAL_TIM_Base_Start_IT(&htim6); // Start the timer

Kart the timer

Kart the timer
```

#### STM32 TIMERS – RESOURCES

- General-purpose timer cookbook for STM32 microcontrollers
  - https://www.stmicroelectronics.com.cn/content/ccc/resource/technical/document/application\_note/group0/91/01/84/3f/7c/67/41/3f/DM00236305/files/DM00236305.pdf/jcr:content/translations/en.DM00236305.pdf

#### STM32L4 Timers

https://www.st.com/content/ccc/resource/training/technical/product\_training/c4/Ib/56/83/3a/aI/47/64/STM32L4\_WDG\_TIMERS\_GPTIM.pdf/files/STM32L4\_WDG\_TIMERS\_GPTIM.pdf/jcr:content/translations/en.STM32L4\_WDG\_TIMERS\_GPTIM.pdf

# TOGGLETHE LED USING A TIMER

### TOGGLE THE LED USING A TIMER

Use the previously configured timer to toggle the green LED every I second.

- I. Use CubeMX to configure a simple timer
- 2. Configure the board clock to provide an APB clock equal to 60 MHz
- 3. If needed, pre-scale the clock to a suitable frequency for the timer
- 4. Set the timer counting period
- 5. Start the timer **using the blue button**
- 6. Using the interrupt callback, **toggle the green LED**

# CHANGE THE TIMER COUNTING PERIOD

#### CHANGE THE TIMER COUNTING PERIOD

Using an interrupt generated by an external input, cycle the timer counting period between 0 - 0.25s - 0.5s - 1s - 2s

- I. Use CubeMX to configure a simple timer
- 2. Configure the board clock to provide an APB clock equal to 60 MHz
- 3. If needed, pre-scale the clock to a suitable frequency for the timer
- 4. Set the timer counting period
- 5. Using the interrupt callback, **cycle the counting period** of the configured timer by updating the relative register.